

IFR FLYING - FLIGHT PLANNING

Load FSX

Select aircraft – B737

Select Current Location

Canada

Nova Scotia

Halifax

Halifax Intl

Gate 12

OK

FLY NOW

Immediately Set Parking Brakes (Ctrl .)

Activate top menu (ALT)

Under Flights – select Flight Planner

DEPARTURE LOCATION

This will be set at Gate 12 – HFX INTL (Change if desired)

OK

DESTINATION

Country – USA

State – Maine

City – Bangor – (Then select Bangor Intl)

OK

FLIGHT PLAN TYPE

Select IFR

ROUTING

Select VOR to VOR

GENERATE

Select FIND ROUTE

On Route page, change Cruising Altitude to 34,000 (either retype or click up)

Go to Bangor – Get Airport page – PRINT (This should list ILS
Frequencies)

Select NAV LOG

Print NAV LOG

OK

OK

SAVE – YES - (Replace ???)

(MOVE TO AIRPORT?) - YES